


ROASTER® 

MANUAL

PARRILLA GRILLS

By BLOKAN GP





**PLEASE READ ALL THE INSTRUCTIONS IN THIS
MANUAL THOROUGHLY BEFORE INSTALLING AND
OPERATING THE PARRILLA GRILL.
RETAIN IT FOR FUTURE REFERENCE.**

IMPORTANT

The present manual will help you use the product safely.

- Read all instructions before installing and using the equipment.
- Save these instructions.
- Keep the manual within reach for future reference.
- The pictures, technical drawings and general information in this manual might have been modified since its first edition.

When this rotisserie is not properly installed, a fire may result. To reduce risk of fire, follow the installation instructions.

Please read this manual carefully before you install the Parrilla Grill.

Failure to follow instructions may result in property damage, body injury or death.

ROASTER[®] 

BIOKAN

Since 1989
KOZANI, GREECE

The Roaster Charcoal Ovens n' Grills are the result of the long-term experience of BIOKAN G.P. in manufacturing open grills in combination with the Greek tradition of cooking in wood ovens and on charcoal grills. BIOKAN GP was founded in 1989 and, since then, we have been manufacturing stainless steel equipment for restaurants and other food service establishments. BIOKAN GP has always manufactured products that are efficient, easy to install and maintain, and products that meet the highest standards. The know-how and the experienced staff, as well as the avant-garde machinery has led to the production of high-quality charcoal ovens and grills, which combine both modern and ergonomic design with functionality.

BIOKAN GP boasts one of the most technologically advanced digitized production lines of stainless-steel constructions in Greece using a production management software to ensure quality and believes in continuous improvement and evolution. Products are upgraded so that they can always respond to the needs of any food service establishment as evolution and improvement are our main concerns.

Our Vision is to continue being a customer centric business which has determined our development, commercial expansion, and strategy since our foundation and to keep providing our clients with high quality products and services at fair prices.

As a result, we have established long-term and fruitful business relations with the companies we have cooperated with for the past few years.

We always offer our clients the best pre-sales and after - sales support.

CONTENTS

BEFORE USING PARRILLA GRILL

Before Using Parrilla Grill.....	5
----------------------------------	---

ROASTER PARRILLA MODELS

Parrilla Grill Models	7
Parrilla Grills Technical Information.....	10
Drawings.....	11
Components.....	12
Parrilla F-SERIES Technical Information.....	13
Drawings.....	14
Components.....	15
Parrilla BUILT IN Technical Information.....	16
Drawings.....	17
Components.....	18

COMPONENTS

Components.....	19
Accessories.....	20

INSTALLATION INSTRUCTIONS

Warnings.....	21
---------------	----

CLEANING AND MAINTENANCE

Cleaning.....	22
Maintenance.....	23

WARRANTY

Warranty.....	24
---------------	----

CONTACT DETAILS

Contact Details.....	25
----------------------	----

1.1 BEFORE USING THE PARRILLA GRILL



Place the Parrilla grill on a hard level, non-combustible, stable surface (concrete, ground, etc.), which can support the weight of the grill. Never place the grill on wooden or other combustible surfaces.



The Parrilla grill is hot when in use. To avoid burns wear protective gloves or oven mitts.



DO NOT touch any surface of the Parrilla grill, as the surfaces are at high temperature.



DO NOT attempt to move the Parrilla grill when it is in use. Do NOT clean the Parrilla while it is still hot.



Place the Parrilla grill on a surface which is NOT accessible to children and pets. Close supervision is necessary when the grill is in use.



Never leave burning charcoal or ashes in the Parrilla grill unattended. Before the grill can be left unattended, the remaining charcoal/wood and the ashes must be removed. Do NOT pour ashes into flammable or thermo-deformable buckets made from materials like plastic, rubber, wood or similar.

1.1 BEFORE USING THE PARRILLA GRILL



Store the unit in a safe and dry place. Rain or adverse weather conditions may damage the Parrilla grill.



Do NOT put off the fire by throwing water in the grill.



Do NOT throw the charcoal into the Parrilla grill but place them gently.



DO NOT store lighter fluid and other flammable liquids or materials under the Parrilla. Put any flammable material at least 30 cm away from the sides or the top of the grill.



DO NOT use gasoline, kerosene or alcohol to fire up the charcoal. Using any of these or similar products could cause an explosion and possibly lead to severe injury.



DO NOT install this appliance in any area where it may be affected by any adverse conditions such as steam, grease, dripping water, high temperatures, or any other adverse conditions.



Respect the frequency and guidelines of maintenance and cleaning recommended by BOKAN GP in this manual.



When this equipment is not properly installed, a fire may result. To reduce risk of fire, follow the installation instructions.



BOKAN GP will not be responsible of any damages caused to people, parts or installations due to improper use or maintenance of the Parrilla Grill.



The legislation of the country and town, where the equipment is going to be installed, must be checked since norms and regulations may ask for further safety measures than the ones exposed in this manual

2.1 PARILLA GRILL MODELS


GP1G Counter-top
Roasting Area 630x620 mm



GP1GC With Cabinet
Roasting Area 630x620 mm



GP2G Counter-top
Roasting Area 1000x620 mm



GP2GC With Cabinet
Roasting Area 1000x620 mm



GP3G Counter-top
Roasting Area 1500x620 mm



GP3GC With Cabinet
Roasting Area 1500x620 mm




2.2 PARRILLA GRILLS F-SERIES MODELS

GPFS25 Counter-top
Roasting Area 2X 500x620 mm



GPFS25C With Cabinet
Roasting Area 2X 500x620 mm



GPFS26 Counter-top
Roasting Area 2X 630x620 mm



GPFS26C With Cabinet
Roasting Area 2X 630x620 mm



GPFB26 Counter-top
Roasting Area 2X 630x620 mm



GPFB26C Counter-top
Roasting Area 2X 630x620 mm




2.3 PARRILLA GRILLS BUILT IN MODELS


GP1GM – BUILT IN
Roasting Area



GP2GM - BUILT IN
Roasting Area 2X



GP3GM – BUILT IN
Roasting Area 3X 500X620 mm



2.4 PARRILLA GRILLS TECHNICAL INFORMATION

TECHNICAL INFORMATION GP1G/GP1GC

Roasting area	630X620 mm	
Fire up time	30 min average	
Charcoal daily consumption*	Charcoal 16 – 18 kg	
Broiling temperature	200 °C to 250 °C	
Exhaust rate	2.000 m3/h	
Net weight GP1G/GP1GC	130 kg	160 kg

TECHNICAL INFORMATION GP2G/GP2GC

Roasting area	2X 500X620 mm	
Fire up time	30 min average	
Charcoal daily consumption*	Charcoal 18 – 22 kg	
Broiling temperature	200 °C to 250 °C	
Exhaust rate	3.000 m3/h	
Net weight GP2G/GP2GC	190 kg	220 kg

TECHNICAL INFORMATION GP3G/GP3GC

Roasting area	3X 500X620 mm	
Fire up time	30 min average	
Charcoal daily consumption*	Charcoal 30 – 36 kg	
Broiling temperature	200 °C to 250 °C	
Exhaust rate	4.000 m3/h	
Net weight GP3G/GP3GC	250 kg	280 kg

INSTALLATION

Clearance with non-flammable equipment	100 mm
Clearance with flammable equipment	300 mm

INCLUDED ACCESSORIES

Parrilla “V” grill grates
Upper Grill Racks
Ash Collector Drawer
Grease Collector
Charcoal Shovel
Charcoal Starter
Scraper
Poker
Fire Bricks
Packaging

OPTIONAL ACCESSORIES


Parrilla “V” grill grate
Parrilla Rod grill grate
Upper grill rack
Frontal GN Supports
Thermal Protection
Poker
Grill Scraper
Ash shovel
Charcoal Starter

* The quantity of charcoal consumption depends on the cooking duration and the quality of the charcoal used.


For the firing-up procedure 5-8 kg of charcoal is needed. The Parrilla grill must be reloaded with approximately 4kg of charcoal every 2 hours.

2.4.1 DRAWINGS


DIMENSIONS GP1G/ GP1GC (mm):




DIMENSIONS GP2G/ GP2GC (mm):



DIMENSIONS GP3G/ GP3GC (mm):



2.4.2 COMPONENTS PARRILLA GRILLS



2.5 PARRILLA F-SERIES TECHNICAL INFORMATION

TECHNICAL INFORMATION GPFS25/ GPFS25C

Roasting area	2X 500X620 mm	
Fire up time	30 min average	
Charcoal daily consumption*	Charcoal 27 – 35 kg	
Broiling temperature	200 °C to 250 °C	
Exhaust rate	4.600 m3/h	
Net weight GPFS25/ GPFS25C	200 kg	250 kg

TECHNICAL INFORMATION GPFS26/ GPFS26C

Roasting area	2X 630X620 mm	
Fire up time	30 min average	
Charcoal daily consumption*	Charcoal 30 – 38 kg	
Broiling temperature	200 °C to 250 °C	
Exhaust rate	5.100 m3/h	
Net weight GPFS26/ GPFS26C	230 kg	280 kg

TECHNICAL INFORMATION GPFB26/ GPFB26C

Roasting area	2X 630X620 mm	
Fire up time	30 min average	
Charcoal daily consumption*	Charcoal 35 – 45 kg	
Broiling temperature	200 °C to 250 °C	
Exhaust rate	5.600 m3/h	
Net weight GPFB26/ GPFB26C	275 kg	350 kg

INSTALLATION

Clearance with non-flammable equipment	100 mm
Clearance with flammable equipment	300 mm

INCLUDED ACCESSORIES

Parrilla "V" grill grates
Upper Grill Racks
Ash Collector Drawer
Grease Collector
Charcoal Shovel
Charcoal Starter
Scraper
Poker
Fire Bricks
Packaging

OPTIONAL ACCESSORIES


Parrilla "V" grill grate
Parrilla Rod grill grate
Upper grill rack
Thermal Protection
Frontal GN Supports
Poker
Grill Scraper
Ash shovel
Charcoal Starter

* The quantity of charcoal consumption depends on the cooking duration and the quality of the charcoal used.


For the firing-up procedure 10-15 kg of charcoal is needed. The Parrilla grill must be reloaded with approximately 4kg of charcoal every 2 hours.

2.5.1 DRAWINGS F-SERIES MODELS


DIMENSIONS GPFS25- GPFS25C (mm):





DIMENSIONS GPFS26- GPFS26C (mm):




DIMENSIONS (mm):



GPFB26- GPFB26C



2.5.2 COMPONENTS F-SERIES



2.6 PARRILLA BUILT IN TECHNICAL INFORMATION

TECHNICAL INFORMATION GPM1G

Roasting Area	500x620
Dimensions Without packaging	700X760X980 mm
Dimensions With packaging	780X900X1160 mm
Weight (NET)	130 kg

TECHNICAL INFORMATION GPM2G

Roasting Area	2X 500x620
Dimensions Without packaging	1250X760X980 mm
Dimensions With packaging	1330X900X1160 mm
Weight (NET)	190 kg

TECHNICAL INFORMATION GPM3G

Roasting Area	3X 500x620
Dimensions Without packaging	1800X760X980 mm
Dimensions With packaging	1880X900X1160 mm
Weight (NET)	250 kg

INSTALLATION

Clearance with non-flammable equipment	100 mm
Clearance with flammable equipment	300 mm

INCLUDED ACCESSORIES

Parrilla "V" grill grates
Upper Grill Racks
Grease Collector
Charcoal Shovel
Charcoal Starter
Scraper
Poker
Packaging




OPTIONAL ACCESSORIES

Parrilla "V" grill grate
Parrilla Rod grill grate
Upper grill rack
Poker
Grill Scraper
Ash shovel
Charcoal Starter




* The quantity of charcoal consumption depends on the cooking duration and the quality of the charcoal used. For the firing-up procedure 10-15 kg of charcoal is needed. The Parrilla grill must be reloaded with approximately 4kg of charcoal every 2 hours.

2.6.1 DRAWINGS GP1GM – BUILT IN




DIMENSIONS GPM1G (mm):




DIMENSIONS GPM2G (mm):












DIMENSIONS GPM3G (mm):








2.6.2 COMPONENTS BUILT IN



3.1 COMPONENTS

IMAGE	DESCRIPTION	CODE
	"V" grill grate Rod grill grate	GRV
	Removable Upper rack	PRLSH
	Steering Wheel	SWP
	Wheels	CGA12
	Fire bricks	FBRK
	Ash Collector Drawer	PACD
	Cabinet	CABDINX
	Charcoal grate	CHGP
	Removable drip pan collector	RGP

3.2 ACCESSORIES

IMAGE	DESCRIPTION	CODE
	Charcoal Starter	CHST
	Poker	POK
	Ash Shovel	CSH
	Grill scraper	GSC
	Wire Brush	CGB

4.1 WARNINGS



Before firing-up the Parrilla grill for the first time, remember to remove all the plastics that are covering the exterior of the rotisserie.



This product may have been dispatched in more than one packages. Check that all items and accessories have been received as ordered. Keep all instructions/manuals.



Do NOT use flammable liquids to fire-up the charcoal. Only use charcoal as fuel for the grill.



DO NOT place any obstructions that may block the access for the maintenance or the service of the Parrilla grill. DO NOT modify or damage the legs of the Parrilla grill.



Always place the Parrilla grill under an exhaust hood.



In all the installation options, it is important to keep the components of the hood clean (see Chapter 5, Cleaning and maintenance).



You must fire-up the Parrilla grill before starting roasting. All the firing-up process must be done without any accessories on the Parrilla grill.



Place the Parrilla grill at a distance of at least 100 mm away from the wall or any other cooking appliance.

5.1 CLEANING



Perform the operations when the grill is cold to avoid burns.



Do NOT use chemical products to clean the grill.



Do NOT pour ashes into flammable or thermo deformable recipients made from materials like plastic, rubber, wood or similar.



DO NOT splash water directly into the grill and DO NOT use any water or any kind of liquid.



Clean with e grease remover and a cloth or brush.

- ✓ It is necessary to clean the grill racks and the other roasting accessories after every use.
- ✓ Remove the grill racks and wash them with a grease remover and a brush or cloth.
- ✓ Do NOT use a corrosive grease remover to clean the outside of the grill.
- ✓ Clean the exterior casing of the grill with a grease remover and a cloth.
- ✓ Remove the ash collector drawer and clean it with a grease remover and a brush.
CAUTION! Ashes must be placed in a metal container which should be placed on a non-combustible surface or on the ground, away from combustible materials, until their final disposal.
- ✓ The fire grates should be cleaned twice a month with a wire brush. Change the position of the fire grates every time you clean them; turn them upside down and put the ones of the middle to the sides, and the ones of the sides in the middle.
CAUTION! DO NOT use water.

5.2 MAINTENANCE



Make sure that the grill is cold before performing any maintenance operation.



Wear protective gloves or oven mitts.



It is forbidden to perform any modification to the equipment unless it has been approved by BOKAN GP before.



Do NOT use pieces or parts of other companies.



BOKAN G.P will not be responsible of damages provoked to people, parts or installations caused by an improper use or maintenance of the Parrilla grill.



All inspections must be carried out by qualified personnel.

6.1 WARRANTY



BIOKAN GP guarantees ONE-year warranty from the purchase date of this product, against any defect in the materials and the components used during its fabrication.

THIS WARRANTY WILL NOT BE VALID UNDER THE FOLLOWING CIRCUMSTANCES

1. When the Buyer or the End user do not follow strictly the instructions of use in this manual.
2. When the product has been misused, damaged, or exposed to any liquid or corrosive substance or for any other faults attributable to the Buyer or End user.
4. When the product has been modified or repaired by non-qualified personnel.
5. When the fault is due to the normal wearing out of the rotisserie and its parts due to long term use.
6. When the damage is caused by liquids, chemicals or products that should not be poured inside the oven.

NOTES:

- Repair or substitution is possible only when a product was originally defective (at the time of delivery).
- The Buyer or the End user is responsible for any damage caused due to wrong or improper use.
- The Buyer should inspect the products immediately after the delivery and any complaints or arguments must be sent to our company within five (5) business days.
- The risk of loss, destruction, or damage of the product during the shipping is the Buyer's or carrier's responsibility, even if the shipping order has been given by our Company at the request of the Buyer.
- All repairs during the guarantee periods of 12 months, are performed in our factory in Greece.
- The Buyer is responsible for the shipping of the products and covers exclusively the shipping cost.
- If the problem to be repaired is caused by an incorrect use or installation a charge will be applied, even if the product is in the warranty period.

No other warranty, verbal or written, different that the one expressed here will be accepted by BIOKAN GP.



CHARCOAL OVENS N' GRILLS

By BLOKAN G.P.



www.roastergrills.com



sales@roastergrills.com



www.facebook.com/RoasterOvens



https://www.instagram.com/roaster_ovens



<https://www.linkedin.com/company/roasterovens/posts/?feedView=all>



<https://www.youtube.com/channel/UCjOpxGWZamP7FVeQ2Dx45yA>

FACTORY

2nd km. Kozanis – Neas Nikopolis, 50100, Kozani, GREECE

Tel.: +30 2461 0 36538

HEAD OFFICES

312 Syggrou Av, Kallithea, 17673, Athens, GREECE

Tel.: +30 21 0 2203458

ATHENS SHOWROOM

10 Achaion St., Paleo Faliro 17564, Athens Greece